

Topex & Talunex

Get your
free adaptor
from Certis

New adaptor for your Topex[®] Applicator,
for use with the new size Talunex[®] flask,
now available

it's as easy as 1, 2, 3



Fit the adaptor to the applicator and strengthen the connection by tightening the screw (highlighted above)



Make two openings in the top of the Talunex flask (this should only be done with the Topex Opener)



Twist the flask on to the applicator immediately to make an airtight connection

Having a Topex Adaptor is necessary in order to continue to use Talunex in a responsible manner

Topex & Talunex

Still made for each other and continuing to ensure, sure shot control of rabbits, rats and moles

ALWAYS READ THE LABEL. USE PESTICIDES SAFELY.
TALUNEX CONTAINS ALUMINIUM PHOSPHIDE.
MAPP 13798.
To be used only by professional, trained operators.

CERTIS

Certis -1b Mills Way - Boscombe Down Business Park
Amesbury - Wiltshire - SP4 7RX - UK
Tel: +44 (0) 1664 820 052 - Fax: +44 (0) 1664 820 216
Email: certis@certiseurope.co.uk - Web: www.certiseurope.co.uk